TOP GLOVE SDN. BHD

WORK INSTRUCTION

Production Process Control Testing: Chlorine Test (Titration)

Purposes/Function/Objective

- To determine percentage of chlorine in chlorine

Materials/ Chemicals/ Tools/Equipment

- 1) Potassium Iodide
- 2)0.1 M Sodium Thiosulphate
- 3)25 ml Pipette
- 4) 100 ml conical flask

Specification

calculation:-

% Chlorine ppm = V x 0.0142 x 10000

Where is:

V=Volume of Na₂SO₂O₃ solution required for titration ml

Form

LA/F02

References:

(Effective Date: 02/05/2011)

- nil

Procedures




Apparatus use for Chlorine test



Weigh 0.5g potassium iodide into conical flask.



End Point: Brown to colorless



Add (pipette) 25ml chlorine sample into the conical flask



Titrate with 0.1M of Sodium Thiosulphate $(Na_2SO_2O_3)$





Calculation: %Chlorine ppm = V x 0.0142 x 10000

Prepared by:	Verified by:	Approved by:
Noor Azura Binti Azman	Al-Fadilah Mohamad	Noor Akilah Saidin
QA/MQC Asst Supervisor	QA Executive II	QA Deputy General Manager