

WORK INSTRUCTION

Incoming Raw Latex Testing : Coagulum Test

Purposes/Function/Objective

- To determine coagulum content in raw latex
(To conduct is MST is out of specification)

Materials/ Chemicals/**Tools/Equipment**

1. Latex
2. Stainless Steel Wire Mesh 80
3. Analytical Balance
4. Beaker
5. Oven (heat at 100° C)

Specification

Coagulum Content in ppm=

$$\left(\frac{(B)-(A) \times 10,000 \times 100}{(C)} \right)$$

Where is ;

A = Weight of stainless steel wire mesh

B = Weight of wire mesh after dried

C = Weight of sample


Form/s:

- LA/F06


References :

- ISO 706

(Effective Date : 02/05/2011)

Procedures


Weigh stainless steel wire mesh sheet (80 meshes) to 4 decimal points. (A)



Weigh in a beaker 200 g of latex to 4 decimal points. (C)



Pour latex onto top of wire mesh.



Rinse wire mesh with distilled water until it is free from latex.



Dry wire mesh in oven at 100°C for 1 hour.



Let wire mesh to cool to room temperature and reweigh wire mesh to 4 decimal place. (B)

Coagulum Content in ppm=

$$\left(\frac{(B)-(A) \times 10,000 \times 100}{(C)} \right)$$

Prepared by:	Verified by:	Approved by:
Noor Azura Binti Azman	Al-Fadilah Mohamad	Noor Akilah Saidin
QA/MQC Asst Supervisor	QA Executive II	QA Deputy General Manager