

WORK INSTRUCTION

Production Process Control Testing : Alkaline Test (Titration - CFC/FCL/FC3).

Purposes/Function/Objective

- to ensure the percentage of alkaline is within standard for rinse former.

Materials/ Chemicals/Tools/Equipment

- 1) 0.1M $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$
(Sodium Thiosulphate Hydrate)
- 2) Phenolphthalein
- 3) 50ml conical flask
- 4) Pipette
- 5) Cylinder
- 6) 0.1M HCl

Specification

- calculations:-

$$\% \text{ of CFC} = v \times 0.16$$

Where is:

v = volume of 0.1M HCL
Solution used(ml)

Form/s

- LA/F04

References :

- nil

(Effective Date : 02/05/2011)

Procedures


Put 25ml sample into measuring cylinder



Transfer the sample into 50ml conical flask



Add 3 drop of phenolphthalein indicator.



Add 1ml of 0.1M $\text{Na}_2\text{S}_2\text{O}_3 \cdot 5\text{H}_2\text{O}$ (Sodium Thiosulphate Hydrate)



Titrated the mixture with 0.1M HCl (V)



End point:- Pink to colorless

7 Calculation :
% of CFC
= $v \times 0.16$

Prepared by:	Verified by:	Approved by:
Noor Azura Binti Azman	Al-Fadilah Mohamad	Noor Akilah Saidin
QA/MQC Asst Supervisor	QA Executive II	QA Deputy General Manager