

WORK INSTRUCTION

Incoming Raw Latex Testing : Total Solid Content Test

Purposes/Function/Objective

- To determine the total solid content in 60% DRC HA / MA Concentrated Latex and Synthetic Latex)

Materials/ Chemicals/Tools/Equipment

1. Natural Rubber - Sample
2. Nitrile Butadiene rubber - Sample
3. Aluminium foil diameter 2.5cm
4. Oven 150°C
5. Spatula
6. Analytical balance
7. Timer

Specification:

TSC Calculation:

$$\% \text{ of TSC} = \frac{C-A}{B} \times 100\%$$

A : Weight of aluminium foil

B: Weight of sample

C : Weight after Drying


Record in the inspection form

Form/s


- LA/F08

References :

- ISO 124

Procedures

Tare analytical balance



Weigh aluminium foil and record as (A)




Weigh 0.5 g sample and record as (B)



Dry sample into oven (150°C) for 30 minutes



Place sample in desiccator for two minutes



Reweigh sample and record as (C)

7

TSC Calculation:

$$\% \text{ of TSC} = \frac{C-A}{B} \times 100\%$$

A : Weight of aluminium foil
B: Weight of sample
C : Weight after Drying
Record in the inspection form

Prepared by:	Verified by:	Approved by:
Noor Azura Binti Azman	Al-Fadilah Mohamad	Noor Akilah Saidin
QA/MQC Asst Supervisor	QA Executive II	QA Deputy General Manager

(Effective Date : 02/05/2011)

TOP GLOVE SDN. BHD

WORK INSTRUCTION

Incoming Raw Latex Testing : Dry Rubber Content Test

Purposes/Function/Objective

- To determine the percentage of dry rubber content in 60% DRC HA / MA Concentrated Latex

Materials/ Chemicals/

Tools/Equipment

1. Natural Rubber - Sample
2. Petri dish
3. Oven 150° C
4. Cylinder
5. Spatula
6. Analytical balance
7. Timer

Specification

DRC Calculation:

$$\% \text{ of DRC} = \frac{C-A}{B} \times 100\%$$

A : Weight of petri dish

B: Weight of latex sample,g

C : Mass of weighing petri dish+dried sample, g

Form/s

- LA/F08

References :

- ISO 126

Procedures



Weight petri dish and record as (A)



Weight approximately 5g latex into petri dish and record as (B)



Add 5ml distill water



Add 20ml 5% acetic acid

7



Put inside oven/water bath for 15 minutes. Take out after 15 minutes, press and wash the latex with running water



Dry the coagulum sheet in a rented air oven at 150°C for 45 minutes.



Cool the dried coagulum in room temperature and weight and record as (C)

8 DRC Calculation:

$$\% \text{ of DRC} = \frac{C-A}{B} \times 100\%$$

A : Weight of petri dish

B: Weight of latex sample,g

C : Mass of weighing petri dish+dried sample, g.

(Effective Date : 02/05/2011)

Prepared by:	Verified by:	Approved by:
Noor Azura Binti Azman	Al-Fadilah Mohamad	Noor Akilah Saidin
QA/MQC Asst Supervisor	QA Executive II	QA Deputy General Manager